





INSTRUCTIONS USAGE:

- ⇔ Hardware connection
- Software handling






Before you can use your tool you need to connect the iDS to your computer and a vehicle or vessel you like to diagnose.



After you connected computer – iDS – vessel/vehicle you can start your software



Choose brand and model





Software general information

- The software interface is in general the same for each application. This makes it easy to handle different applications.
- Depending on the manufacturer of the vehicle or vessel you have more or less services, setting, diagnostics, live data, actuators, etc. to choose from.
- Each software application is basically self-explaining. However, there are some special things that might be interesting and/or new for the user (please check out "Good to know"!


The following screen shots are examples how to work with the software applications




Select the correct brand/model from the "drop down menu".








Always the first button to use "Connect with the ECM". When the connection has been established the vehicle vessel data will be shown in the data window (upper right corner)










All other buttons are now highlighted and ready to use







Service








Diagnostic











Erase Faults








Module







Actuators








Live Data

















Save/Print



Run Diagnostic first.


With the fault codes on the screen, click the "SAVE" button.




Type in your information and click "SAVE" button.








Click on History




Choose Dates "from" - "to"







Choose one of the files



Click "Print" to print out (or to file) the information






ECM power

Whatever vehicle or vessel you try to connect to, it is a MUST to power up the ecm.

An ECM that is not powered up is impossible to connect to!

- Always have a lanyard or key for the power up attached to the vehicle/vessel.
- If possible/necessary turn on the ignition.
- For some tasks the engine even has to run
- Make sure you're using external power if necessary (check the special power up for the relevant application)

Software application "OPTIONS"



- It is **VERY important to choose the correct software option** from the respective drop down menu! Most models have a unique protocol and a unique developed way of connection. Choosing a wrong software option can result in damaging the tool.

Tool handling

- During software starting process and / or during model updates, please make sure not to:
 - power down the computer
 - run laptop battery empty
 - disconnect USB cable

This could damage the iDS!





Software updates

- It is very important to keep your software up to date. Please check frequently for updates. Our engineers are working very hard and update every application multiple time during the year.
- If you ever experience a problem to establish a connection to a vehicle/vessel, before you asked for support PLEASE check if you're using the latest software version.











CHECK FOR ACTUAL/AVAILABLE SOFTWARE VERSIONS







Support Request

Before you use the support request option, please visit our <u>online support page</u>. Many issues
can be fixed by checking this page first. This gives you a quicker solution and is saving us time
on the other hand.

Support page



- In case you need to ask for help, please make sure you're always providing the following information:
 - brand
 - model
 - vear
 - what connector cable are you using
 - what software option are you using
 - issue
 - screen shot of the complete software screen
 - picture of the ecm

You can use our online support request form



Or if you need to attach a picture etc. you can just use our regular email contact: tool@sws1.com

(We're not using the regular email address on the web site, because of to many "Spam" emails)